

## EN Smart motion detector Instruction manual for the electrical connection and for commissioning

#### Item no. 11771001



## Contents

1.	These instructions	
2.	Hazard symbols2.1Levels of danger and signal words2.2Symbols and depictions used	5
3.	Safety Instructions         3.1       Intended Use         3.2       Incorrect Use         3.3       Required Expert Knowledge of the Installer         3.4       Glossary - Definition	7 8 9
4.	Included in delivery	11
5.	General View of the Operating Unit5.1General View of the Installation Housing5.2Electrical connections5.3Indicator Lights5.4Functions and Button Combinations	13 14 15
6.	Product Description	
7.	Technical Specifications7.1Detection Ranges and Degrees7.2Detection Levels and Range7.3Factory Settings	30 31
8.	Selecting the suitable Installation Location	33

9.	Connecting the Smart motion detector	
	9.1 Safety Instructions for the Electrical Connection	6
	9.2 Important Information regarding the	_
	Electrical Installation	
	9.3 Carrying out the Electrical Connection	
	9.4 Connection Diagram with Lamp and Push Button	
	9.5 Connection Diagram with Changeover Switch	0
10.	Installation after the Electrical Connection4	1
11.	Important Information regarding the	
	Commissioning	2
12.	Selecting the Operating Mode	3
13.	Manual Operation 44	4
14.	Setting the Sensitivity 4	5
15.	Setting the Brightness Set Limit	б
16.	Setting the Run-on Time 49	9
	Logging DuoFern Devices On / Off	
	17.1 Logging on DuoFern Devices	
	17.2 Logging off DuoFern Devices	3
	17.3 Clearing Process in the DuoFern Network	4
18.	Hardware Reset in the event of Unit Failure	5
19.	Erase all Settings, Software Reset	б
20.	Dismounting	7
21.	Simplified EU Declaration of Conformity	8


...describe how to install, connect and operate the Smart motion detector.

## 1.1 Application of this manual

- Before you begin, please read this manual through completely and follow all the safety instructions.
- Please also read the instruction manuals of the accessories (if available) as well as the instructions of the respective connected appliance.
- This manual is a component of the product. Please store it in an easily accessible place.
- When passing the Smart motion detector on to a third party, this manual must be passed on as well.
- Damage resulting from non-compliance with these instructions and safety instructions will void the guarantee. We shall assume no liability for any consequential damage.

Í

The following hazard symbols are used in this instruction manual:



### 2.1 Levels of danger and signal words



This hazard will lead to serious injury or death if not avoided.

\Lambda WARNING!

This hazard may result in serious injury or death if not avoided.

## **CAUTION!**

This hazard may result in minor or moderate injury if not avoided.

## ATTENTION!

This hazard may lead to property damage.

	м
с	N'

Depiction	Description
1.	Procedures
2.	
<b>♦</b>	Itemisation
1) or a)	Lists
i	further useful information
	Please read the respective manual
*	Indicator light flashes red
-` <b>\</b> .	Indicator light flashes green
•	Indicator light lights up red
•	Indicator light lights up green
0	Indicator light is off

## 3. Safety Instructions



#### The use of defective equipment can lead to personal injury and damage to property (electric shocks / short circuiting).

- Never use defective or damaged equipment.
- Check that the Smart motion detector is intact.
- Consult our customer service department in the event that you discover damage.

### 3.1 Intended Use

Only use the Smart motion detector for connecting and controlling electrical appliances (e.g. lighting etc.) within the permissible load limits, see "Technical Specifications".

#### **Operating conditions**

- Only use the Smart motion detector in dry rooms.
- A 230 V / 50 Hz power supply, together with a site-provided disconnecting device (fuse), must be available at the installation location.

The installation and operation of the radio systems is only permitted for those systems and devices where a malfunction in the transmitter or receiver would not cause a danger to personnel or property or where this risk is already covered by other safety equipment.



Radio systems which transmit on the same frequency can cause interference.

### 3.2 Incorrect Use

Using the Smart motion detector for any other purpose than previously mentioned is not permissible.



# Improper use can lead to serious injuries or property damage.

- The Smart motion detector is not suitable to be used for an electrically safe disconnection.
- Never use the radio system and its components for the remote control of appliances and systems with increased safety-relevant requirements or where there is an accident risk. Such applications require additional safety equipment. Observe the respective statutory regulations for the installation of such systems.

8



There is a risk to life caused through short circuiting and electric shocks if the Smart motion detector is used outside or in damp rooms.

 Do not install and use the Smart motion detector outdoors or in damp rooms.

### 3.3 Required Expert Knowledge of the Installer

The electrical connection, installation and commissioning of the Smart motion detector must only be carried out by a qualified electrician in accordance with the instructions in this manual.

#### DuoFern


i

 HOMEPILOT radio technology for controlling compatible products.

#### **Premium gateway**

• The Premium gateway is a central controller unit for HOMEPILOT radio products.

ELV




#### SELV

Safety Extra-low Voltage

#### **PIR-Sensor**


Passive Infra-red Sensor

Ì




#### Included in delivery

- a) 1 x Operating unit (50 x 50 mm)
- b) 1 x Frame
- c) 1 x Installation housing
- d) 1 x Instruction manual




Ро	s. Symbol		Description	
1)			Sensor panel with motion sensor, indicator lights and lens.	
2)	AUTO		Automatic button [A]	
			<ul> <li>Enable automatic mode (activate motion sensor).</li> </ul>	
	Press for 4 seconds	$\rangle$	<ul> <li>Test and set the sensitivity level. *</li> </ul>	
3)		(	Dn / Off button	
			<ul> <li>Switch the connected appliance on / off; see page 44.</li> </ul>	
	Press for 4 seconds	$\rangle$	<ul> <li>Test and set the brightness value. *</li> </ul>	
4)	MANU	I	Manual button [M]	
			<ul> <li>Enable manual mode</li> </ul>	
			(deactivate motion sensor).	
	Press for 4 seconds	$\rangle$	Test and set the run-on time. *	

<sup>\*</sup> The values are respectively set in combination with the other setting buttons, see table on page 16.



Pos.	Symbol	Description
5)		Plug-in coupling for the operating unit
6)		Claw fasteners and screws
7)		Connecting terminals
8)		Type plate



Pos. Symbol	<b>Description</b>
-------------	--------------------

9)	Ľ N N L L Ext.	Control output [L'] 230 V / 50 Hz ~	
	000000	Connection of the electric appliance.	




**Additional connecting terminals** [L/N] Additional internal wiring of the electric appliance and/or of the external input.

- 11) Voltage supply [L/N] 230 V/50 Hz Connection of the supply voltage.
- 12) L' N N L L Ext.

#### Control input [Ext.]

Connection of an external switch / push-button for manual control on site.



Pos.	Symbol	Description	
13)	• • • • •	<b>Indicator lights 1</b> Status display individual or a	and setting parameters via
	red	Running light	Learning phase during com- missioning.
		permanently lit up	Status display or display of the set value.
		All of the 5 LEDs flash	The overload protection was enables, see page 25.
14)	00000	Indicator light 3	- red / green
	green	flashing	<ul> <li>The current brightness is being measured.</li> <li>The DuoFern login mode is active.</li> </ul>
	red	flashing	<ul> <li>Clearing process is active</li> <li>The DuoFern log off mode is active.</li> </ul>

Function	Button / Button Combination	
	(U) 1 x tap	
	$\bullet$ $\circ$ $\bullet$ $\circ$ $\circ$	
Activate or deactivate the appliance	LED display when automatic mode is active	44
	$\circ \circ \bullet \circ \bullet$	
	LED display when manual mode is active	
Switch on automatic mode	Аито 1 х tap	43
Switch on automatic mode	$\bullet$ 0 0 0 0	45
	MANU 1 x tap	
Switch on manual mode	00000	43
Settings		
Display the set sensitivity level	AUTO 4 sec.	45
Increase sensitivity	AUTO 4 sec. + MANU tap	45
Decrease sensitivity	AUTO 4 sec. + U tap	45
Display the set brightness set limit	(U) 4 sec.	46
Increase brightness set limit	U 4 sec. + MANU tap	47
Decrease brightness set limit	U 4 sec. + AUTO tap	47

## 5.4 Functions and Button Combinations

i

Function	Button / Button Combination	
Adopting the current brightness as the set limit	(U) 8 sec.	47
Display the set run-on time	MANU 4 sec.	50
Decrease the run-on time	мали 4 sec. + аито tap	50
Increase the run-on time	MANU 4 sec. + (U) tap	50
Logging on DuoFern devices	AUTO + (1) 1 sec.	52
Logging off DuoFern devices	(U) + (MANU) 1 sec.	53
Clearing process in the DuoFern network	AUTO + MANU 1 sec.	54
Software reset	AUTO + U + MANU 4 sec.	56

EN

The Smart motion detector serves to control electric appliances and to trigger scenes.

#### The operating principle

As soon as the built-in sensor detects motion within its detection range, the connected appliance (e.g. light, ventilation / heating or air conditioning systems, etc.) is switched on and then switched off again after an adjustable run-on time.

An integrated brightness sensor controls the lighting conditions and determines when the motion detector is enabled. For this, a brightness set limit can be set.

#### Use in the DuoFern network

The Smart motion detector can be integrated into a DuoFern network to use the range of functions of other DuoFern devices such as the Premium gateway.

#### External control input [Ext.] for manual operation on site

For manual operation, one or multiple external switches or push buttons can be connected to the control input [**Ext.**] of the Smart motion detector.

#### Installation and electrical connection

The Smart motion detector is designed as a flush-mounted device for indoor rooms. The electrical connection is carried out by means of the connecting terminals on the reverse side of the installation housing.

With the provided frame, the Smart motion detector can be integrated into customary switches. Suitable switches can be found in the table below.

Switch
Arsys / K1 / S1
Busch-Duro 2000 Si / Reflex Si / alpha exclusive / alpha nea / solo / impuls
Standard-System / S-Color-System / Stainless steel / Standard 55
CD 500 / ST 550 / LS 990 / CDplus and CD, however, with coloured rings
M1 / Atelier / Artec / Trancent / Antique New
Standard / Dialog / Aura
Creo / Tenara
Alessa (plus)




If the supplied frame is replaced by frames of other switches, it may, under circumstances, lead to a reduced degree of detection of 170°.

- Integrated DuoFern radio system
- Stand-alone-mode:

- One time use (switching on/off an electrical appliance)
- Additional control of Smart light receiver devices possible
- Login and control via the Premium gateway possible
- Combined mode:
  - Easy combination of multiple motion detectors via the DuoFern radio system
  - Additional control of Smart light receiver devices possible
  - Login and control via the Premium gateway possible
- Remote control via the DuoFern Premium gateway, Smart remote control and Smart wall switch, etc.
- Control input for an external switch/push button enabling manual operation on site
- Setting options:
  - Sensitivity of the motion sensor
  - Run-on time
  - Brightness set limit
  - Adoption of the current brightness as a new brightness set limit
- Permanent storage of the settings
- Overload protection



#### Application outline - stand-alone-mode




#### Stand-alone-mode

In stand-alone-mode, an electrical appliance (e.g. a lamp) can be directly connected to the Smart motion detector (see page 39) and via this it can be switched on and off.

#### Stand-alone-mode with Smart light receiver devices

In addition, multiple Smart light receiver devices can be logged on to and controlled via the motion detector, see page 51, logging on and off DuoFern devices.

#### Application outline - Stand-alone-mode with multiple Smart light receiver devices: Corridor lighting



#### **Example application:**

## Smart motion detector with multiple Smart light receiver devices: Corridor lighting

Multiple Smart light receiver devices, to which the corridor lighting is connected, are logged on to the motion detector.


As soon as the motion detector detects motion, the connected appliance, and simultaneously all connected actuators, will be switched on. The switch-off is effected automatically after the run-on time.

All logged on Smart light receiver devices are switched on and off, even with manual operation on the device.

İ



#### Application outline - Stairway lighting in combined mode



#### **Combined mode**

Ĭ

In the combined mode, multiple Smart motion detectors can be connected to each other via DuoFern.

In addition, Smart light receiver devices can also be logged on to and controlled via individual motion detectors, see page 51, logging on and off DuoFern devices.

# Information regarding logging on and run-on time in the combined mode



All Smart motion detectors must be respectively connected to each other.



The run-on time must have the identical setting in all motion detectors.

 If the run-on time is altered on one motion detector, this new time will be automatically transferred to all motion detectors.

#### **Example application:**

#### Stairway lighting in combined mode

Installation of multiple Smart motion detectors in one stairway to control the stairway lighting.

The entire stairway lighting is switched on as soon as any of the motion detectors detect motion.

As soon as the run-on time of the motion detector that last detected the motion has expired, the entire stairway lighting is switched off again.

The Smart motion detector features an overload protection. Should the motion detector overheat due to overload, the motion detector will switch off.

#### **Display for overload**



All of the indicator lights flash red.

#### Behaviour when the overload protection is triggered

If the overload protection has been triggered, the connected appliance can no longer be switched on.

#### **Resetting the Overload Protection**

- to reset the protection function, the Smart motion detector must be briefly disconnected from the network
- ٠

Ĭ

or the operating unit must be pulled out of the installation housing.

## What can I do if the overload protection is regularly triggered?



Please check that the connected appliance is not exceeding the load limits, see page 26, "Technical Specifications".

Check that the cable cross-sections of the connecting cables suffice.

EN			
		N	
	-	N'	

Mains supply [L/N]	
Mains supply voltage:	230 V / 50 Hz 🔨
Consumption:	Standby: < 0.6 W

Connection [L' and L / N]		
Switching voltage:	230 V / 50 H	z $\sim$
Maximum switching capacity:	ohmic load,	e.g. bulbs
	-ऴ	12 Α (μ) (Type 1B)
	fluorescent core transfc	ads such as: lamps, drives, iron ormers, e.g. for oltage bulbs such as lbs
		6 Α (μ) (Type 1B)

Connection [L' and L / N]	
Maximum switching capacity:	capacitive loads such as: electronic transformers, AC/DC transformer, e.g. for extra-low voltage lamps such as halogen lamps, LEDs, etc.
	6 A (μ) (Type 1B)

<b>Control input [Ext. ]</b> for an external, manual swit	ch / push button on site
Input voltage:	230 V
Maximum length of the control cable:	10 m



Ì

# Improper use can lead to serious injuries or property damage.

- Due to the small contact distance μ, the
- Smart motion detector is not suitable to be used for an electrically safe disconnection.

ΕA
- 1

DuoFern radio technology	
Transmission frequency:	434.5 MHz
Transmission power:	max. 10 mW
Range:	indoors: approx. 30 m * outdoors: approx. 100 m * depending on the building structure
Max. number of DuoFern devices:	20

General information	
Sensor type:	PIR (Passive Infra-red Sensor)
Permissible ambient tem- perature range:	0 °C to + 40 °C
Protection class:	II (only for use in dry areas)
Dimensions (W x H x D):	50 x 50 x 20 mm (operating unit)
Installation depth:	32 mm (installation housing)
Connecting terminals:	Screw terminals for max. 1.5 mm <sup>2</sup> cables cross-section

#### Setting ranges

Ĭ

<b>J J</b>	
	• • • • • • • • • • • • • • • • • • •
Brightness set limit: *	• • • • • = 10 lux
Five settings available,	• • • • • = 50 lux
see page 46	• • • • • • = 200 lux
	• • • • • = 700 lux **
	• • • • • • • • = 20 sec.
Run-on time:	• • • • • • • = 1 min. **
Five settings available,	• • • $\bigcirc$ $\bigcirc$ = 3 min.
see page 49	• • • • • • = 10 min.
	• • • • • = 30 min.
Sensitivity:	min. to max. Five settings available, see page 45

\* The current brightness can be adopted as a set limit.

\*\* Factory setting


Setting ranges with the Pr	emium gateway
Run-on time: **	0.1 seconds to 55 minutes, con- tinuously adjustable


<sup>\*\*</sup> In the Premium gateway, this setting can be found under the term "stairway function"

Detection ranges	
Degree of detection:	approx. 170°
Detection range:	approx. 10 m
Detection levels:	2 horizontal levels (upper / lower)
Detection zones	upper level = 26 zones
per level:	lower level = 32 zones

EN

#### Image of the degree of detection





- N


Factory Settings	
Automatic mode:	On
Brightness set limit:	700 lux =
Run-on time:	1 minute = $\bullet \bullet \circ \circ \circ$
Sensitivity:	level 4 = $\bullet \bullet \bullet \bullet \circ$
DuoFern participants:	none

#### Avoid installation near disturbing sources




Disturbing sources that cause sever changes to the temperature in the motion detector's range of detection, may lead to errors being triggered.

- Do not install the Smart motion detector in the proximity of the following disturbing sources:
  - Radiators, Heaters




- Windows that are subject to high levels of solar radiation
- Ventilation and air conditioning systems



#### Important information on the installation


- The Smart motion detector is intended for flush mounting. We recommend installation in a deep 58 mm flush-mounted box or in an electronic socket.
- In order to ensure optimal operation, the Smart motion detector should not be installed on a metallic base or near metal objects.
- Select an installation place that is as free from vibrations as possible

#### The ideal installation height (see image)




## Selecting an installation location with an optimum detection or range

The Smart motion detector optimum detection capacity is when moving at a right angle to it. Frontal movement to the Smart motion detector may reduce the sensitivity. Take these factors into consideration when selecting an installation location.



Installation location with a low detection range



Prior to the electrical connection, check that the voltage / frequency on the type plate corresponds to that of the local mains supply.



Ì

Read the specifications relating to the electrical connection detailed in the instruction manual of the electrical appliance used.

### 9.1 Safety Instructions for the Electrical Connection

### 🚹 DANGER!

## There is a risk of fatal electric shocks when touching electrical components.

- All connection and installation work must only be carried out in a de-energised state.
- Disconnect all phases of the mains power supply cable and secure it to prevent any reconnection.
- Check that the system is de-energised.

### \Lambda WARNING!

## Short-circuiting, caused when the Smart motion detector is overloaded, poses a danger to life.

 The maximum switching capacity must not be exceeded, for this, please observe the details in the "Technical Specifications", see page 26.

## 9.1 Safety Instructions for the Electrical Connection

# \Lambda WARNING!

Using incorrect installation housing can lead to personal injury and damage to property (electric shocks / short circuiting).

- Only use the provided installation housing to connect and mount the Smart motion detector.
- Installation housings of other HOMEPILOT products are not compatible.

## 9.2 Important Information regarding the Electrical Installation

## Connection instructions when using an external switch/ push button

- When using the control input [Ext.], you must connect the external switches / push buttons and the Smart motion detector to the same phase [L].
- The maximum length of lead to connect an external switch/ push button must not exceed 10 m.

## Length of insulation stripped:




All leads must be stripped to 6 mm.

## 9.3 Carrying out the Electrical Connection



- 1. Ensure the mains are current-free and check whether the inlet leads are current-free.
- Securely lay the connecting cables right into the flush-mounted box.
- **3.** Remove the insulation on all leads down to 6 mm in length and connect them according to the following connection diagram.
- **4.** After the electrical connection, the installation of the Smart motion detector into the flush-mounted box is carried out, see page 41.

## 9.4 Connection Diagram with Lamp and Push Button




i

The additional connection terminals [N] and [L] are solely intended for wiring the connected electrical appliances and/or an external switch / push button.

 Do not use the connection terminals [N] and [L] for further indoor installations.


ΕN



\* Changeover switch (cross connection also possible)

The additional connection terminals [N] and [L] are solely intended for wiring the connected electrical consumers and/or an external switch / push button.

 Do not use the connection terminals [N] and [L] for further indoor installations.



- 1. Insert the installation housing into the flush-mounted box and fasten it with the screws of the claw fasteners.
- 2. Place the frame onto the installation housing.
- **3.** Subsequently, carefully insert the operating unit into the installation housing .
- 4. Switch on the mains power supply again.
- **5.** The Smart motion detector starts with the learning phase, see next page.

# 11. Important Information regarding the Commissioning

Once the power supply is switched on, the learning phase of the Smart motion detector starts. This learning phase takes approx. 45 seconds; the running light on the indicator lights shows this.

## Running light during the learning phase of 45 seconds



After completion of the learning phase, the electrical appliance is briefly switched on/off and the motion detector is ready for use.

The Smart motion detector has two operating modes: "automatic mode" and "manual mode". If required, the desired operating mode can be enabled at any time.

#### Display the activated operating mode:

**1.** U 1 x The active operating mode is displayed every time the connected appliance is switched on / off, see page 44.

#### **Observe the indicator lights:**



- The automatic mode is enabled if LEDs 1 and 3 light up red.
- The manual mode is enabled if LEDs 3 and 5 light up red.

#### Switching on the automatic mode

**1.** AUTO 1 x The automatic mode is switched on by briefly tapping the AUTO button.

#### Switching on the manual mode

1.MANU 1 xThe manual mode is switched on by<br/>briefly tapping the MANU button.

ப

Manual operation of the Smart motion detector can be carried out with the on/off button or via a push button or switch connected to the control input [**Ext.**].

#### Switching the appliance on/off

1. U or 1 x The off

The connected appliance is switched on or off by briefly tapping the on/off button and/or by pressing the external push button or switch.

- **2.** At the same time, the enabled operating mode is displayed by means of the indicator lights, see page 43.
- **3.** In the automatic mode ○ ○ , the appliance is automatically switched off after the set run-on time, see page 50.



The appliance can also be switched off manually; this stops the run-on time.


 Subsequently, the Smart motion detector is locked for approx. five seconds to prevent unintentional restarting.

#### or

 No run-on time is enabled in manual mode ○ ○ ● ○ ● ; the appliance must be switched off manually. Ĭ

The sensitivity of the Smart motion detector can be set to five different levels.

Observe the following whilst setting the indicator lights:



#### Display the set sensitivity level


<b>1.</b> AUTO 4 sec.	Press and hold the button for approx. 4 seconds.
<b>2.</b> • • • • 0	The sensitivity level is displayed after approx. 4 seconds (example, factory setting).

#### Increase / decrease the level of sensitivity

1.	Αυτο	Press and hold the AUTO button.
2.	Tap on auto + Manu	After approx. 4 seconds, you can increase the sensitivity by additionally tapping on the MANU button.
3.	Тар on 🔤 + 🕖	After approx. 4 seconds, you can decrease the sensitivity by additionally tapping on the on/off button.

With the brightness set limit, you can determine with which level of brightness the motion detector is enabled. There are five different settings.

#### Observe the following whilst setting the indicator lights:



\* Factory setting

#### Display the set brightness set limit

1.	(U) 4 sec.				Press and hold the button for approx. 4 seconds.
2.	• •	٠	0	0	The brightness set limit is displayed after approx. 4 seconds (example).

Ĭ

#### Increase / decrease the brightness set limit

<b>1.</b> (U) 4 sec	c. Press	and hold the button.
<b>2.</b> Tap on ((	the se	approx. 4 seconds, you can increase t limit by additionally tapping on ANU button.
<b>3.</b> Tap on ((	the se	approx. 4 seconds, you can decrease t limit by additionally tapping on the button.

## Adopting the current brightness as the set limit

If required, as an alternative to the setting, the current brightness can be adopted as the set limit.



İ

Ensure that the sensor panel is not covered during the measurement.

1.	(U) 8 sec.			Press and hold the button for 8 seconds.
2.	• •	•	0 0	The set limit is displayed after approx. 4 seconds (example).


<u>i</u>	15.	Se	ttin	g th	e Br	ightness Set Limit EN
3.	0	0	0	0	0	The indicator lights are switched off after approx. 8 seconds and the brightness measurement starts.
4.	0	0	-ờ-	0	0	The measurement is completed as soon as the middle indicator light flashed green.
5.	•	•	0	0	0	Subsequently the measured brightness is displayed as the new set limit.

With the run-on time, you can determine how long the connected appliance (e.g. lighting) remains switched on. There are five different settings.



With the Premium gateway, the run-on time can be infinitely adjusted between 0.1 seconds (pulsed operation) and approx. 55 minutes.

#### Observe the following whilst setting the indicator lights:



 After infinite adjustment in the Premium gateway, the indicator lights approximately display the set run-on time per level.

## Display the set run-on time

i

1.	MANU 4 sec.					Press and hold the button for approx. 4 seconds.
2.	•	٠	•	0	0	The run-on time is displayed after approx. 4 seconds (example).

#### Increase / decrease the run-on time

1.	MANU 4 SEC.	Press and hold the button.
2.		After approx. 4 seconds, you can increase the run-on time by additionally tapping on the on/off button.
3.	Tap on MANU + AUTO	After approx. 4 seconds, you can decrease the run-on time by additionally tapping on the AUTO button.

To use the Smart motion detector with other DuoFern devices, each desired DuoFern device (e.g. Smart light receiver or Premium gateway) must be logged on to the Smart motion detector.



İ

To do so, please read the instruction manual for the respective DuoFern device.

#### Maximum number of connected devices

You can assign a maximum of 20 DuoFern devices to a Smart motion detector.

# 17.1 Logging on DuoFern Devices

1. Switch the desired DuoFern device to the registering mode (please refer to the relevant instruction manual).

<b>2.</b> () + AUTO 1 sec.	Enable the registering mode of the Smart motion detector. Simultaneously press and hold the buttons for 1 second.
	The registering mode remains active for approx. 120 seconds
3. ○ ○ ☆ ○ ○	During the registering process, the middle indicator light flashes green.
4. 0 0 0 0 0	After successful registration, the middle indicator light lights up for approx. 4 seconds and the connected appliance is briefly switched on or off.

Register the next DuoFern device.
 For this, repeat points 1 to 2 or terminate the registration.

#### Pay attention to the middle indicator light



The middle indicator light lights up red if the registration process fails, for example if:

- ٠
  - 20 DuoFern transmitters have already been registered
- An unsuitable device is registered

İ

1. Switch the desired DuoFern device to the log-off mode (please refer to the relevant instruction manual).

<b>2.</b> () + MANU 1 sec.	Enable the log-off mode of the Smart motion detector. Simultaneously press and hold the buttons for 1 second.
	The log-off mode remains active for approx.120 seconds.
3. ○ ○ ★ ○ ○	During the logging off process, the middle indicator light flashes red.
4. 0 0 0 0 0	After successful logging off, the middle indicator light lights up for approx. 4 seconds and the connected appliance is briefly switched on or off.

**5.** Log off the next DuoFern device. For this, repeat points 1 to 2 or terminate the log-off.

#### Pay attention to the middle indicator light



The middle indicator light lights up red if the registration process fails, for example if:

٠

İ

An attempt was made to log-off a DuoFern device that is not logged-on.

This function enables you to log off all DuoFern devices from the Smart motion detector that are no longer accessible via radio.



Not all battery-operated DuoFern transmitters can be logged off in this way.

A software reset must be carried out in order to logout and delete all DuoFern transmitters, see page 56.

1. (AUTO) + (MANU) 1 sec.	Enable the clear function. Simultaneously press and hold the buttons for 1 second.
<b>2.</b> ○ ○ ★ ○ ○	During the logging off process, the middle indicator light flashes red.
3. 0 0 0 0 0	The middle indicator light will light up green for 5 seconds as soon as the clearing process has completed.

#### **Cancelling the clear function**

You can cancel the clearing process at any time by briefly pressing any random button.

We recommend resetting the hardware if a unit fails.



All settings remain unaltered when the hardware is reset.

- 1. Carefully pull the operating unit out of the installation housing.
- **2.** Wait approx. 5 seconds and then carefully reinsert the operating unit into the installation housing.
- **3.** Subsequently check that the Smart motion detector is functioning correctly.
- **4.** If the Smart motion detector is still not reacting, carry out a software reset (see page 56) and test the motion detector with the factory settings.

A software reset can be carried out to reset the Smart motion detector to the original default condition as when supplied.

1. AUTO + U + MANU	Simultaneously press and hold all three buttons for 4 seconds.
2. • • • • • •	Release the buttons as soon as the three indicator lights light up red in a constant manner.

 All settings will be erased and reset to the default factory settings. All of the registered DuoFern devices are automatically logged-off.

i

## 🚹 DANGER!

# There is a risk of fatal electric shocks when touching electrical components.

- Disconnect all phases of the mains power supply cable and secure it to prevent any reconnection. Check that the system is de-energised.
- **1.** Log the DuoFern control device off of the DuoFern network.
- Switch off the mains power, secure it from restarting, and check that the system is de-energised.
- 3. Carefully pull the operating unit off the installation housing.
- **4.** Remove the frame.
- **5.** Release the claw fasteners of the installation housing and pull it out of the flush-mounted box.
- **6.** Disconnect the connecting cable from the installation housing.
- 7. Secure the connection point against restarting and the connecting cable from unintentional contact.

#### CE DELTA DORE RADEMACHER GmbH hereby declares that the Smart motion detector complies with the Directive 2014/53/EU (Radio Equipment Directive).

The full text of the declaration of conformity is available at the following website:

www.homepilot-smarthome.com

#### Warranty terms and conditions

Information on the warranty conditions is enclosed with the product.

i

#### DELTA DORE RADEMACHER GmbH

Buschkamp 7 46414 Rhede (Germany)